





## Microfiche LT-Z 400




Quelle: [www.SuzukiLTZ400.de](http://www.SuzukiLTZ400.de) / Suzuki International Europe GmbH




| Ref No | Part No     | Description                     |
|--------|-------------|---------------------------------|
| 1      | 11401-07811 | Gasket Set                      |
| 2      | 11141-29F01 | • . Gasket, Cylinder Head       |
| 3      | 11173-29F00 | • . Gasket, Cylinder Head Cover |
| 4      | 11241-29F11 | • . Gasket, Cylinder            |
| 5      | 11482-07G00 | • . Gasket, Clutch Cover        |
| 6      | 11483-07G00 | • . Gasket, Magneto Cover       |
| 7      | 12837-24A10 | • . Gasket, Tensioner Adjuster  |
| 8      | 14181-29E02 | • . Gasket, Exhaust Pipe        |
| 9      | 14771-07G00 | • . Connector, Muffler Joint    |
| 10     | 17435-29F00 | • . O Ring, Water Pump Case     |
| 11     | 09168-10002 | • . Gasket (10x14x3.6)          |
| 12     | 09168-12002 | • . Gasket (12.1x16.2x3.7)      |
| 13     | 09280-11005 | • . O Ring (d:2.4,id:11.0)      |
| 14     | 09280-13004 | • . O Ring (d:1.9,id:13.0)      |
| 15     | 09280-22001 | • . O Ring (d:2.4,id:21.8)      |
| 16     | 09280-33004 | • . O Ring (d:3.1,id:32.7)      |
| 17     | 09280-54001 | • . O Ring (d:2.4,id:52.6)      |
| 18     | 09280-71004 | • . O Ring (d:2.6,id:69.6)      |




| Ref No | Part No     | Description          |
|--------|-------------|----------------------|
| 1      | 11170-07G00 | Cover, Cylinder Head |
| 2      | 11173-29F00 | Gasket               |
| 3      | 09106-07009 | Bolt (7x17.5)        |
| 4      | 09106-07010 | Bolt (7x31)          |
| 5      | 09161-11008 | Washer               |
| 6      | 11192-13E00 | Cushion              |



| Ref No | Part No     | Description                   |
|--------|-------------|-------------------------------|
| 1      | 11100-07G00 | Head Assy, Cylinder           |
| 2      | 09206-08001 | • Pin                         |
| 3      | 07120-06403 | • Bolt                        |
| 4      | 07120-06453 | • Bolt                        |
| 5      | 11115-20E70 | Guide, Valve (os.0.3)         |
| 6      | 11141-29F01 | Gasket, Cylinder Head         |
| 7      | 04211-13189 | Pin (l:18)                    |
| 8      | 09103-06504 | Bolt (6x39)                   |
| 9      | 09103-10276 | Bolt (10x175)                 |
| 10     | 09160-10082 | Washer (10.5x19x2)            |
| 11     | 01550-06103 | Plug, Oil Gallery             |
| 12     | 09168-06023 | Gasket                        |
| 13     | 11161-33E00 | Bolt, Cylinder Head Side Face |
| 14     | 11191-13E00 | Washer, Side Face Bolt        |
| 15     | 09482-00516 | Spark Plug (ngk,cr7e)         |
| 15     | 09482-00515 | Spark Plug (denso,u22esr-n)   |
| 15     | 09482-00528 | Spark Plug (ngk,cr6e)         |
| 15     | 09482-00456 | Spark Plug (ngk,cr8e)         |
| 15     | 09482-00458 | Spark Plug (ngk,cr9e)         |
| 15     | 09482-00529 | Spark Plug (denso,u20esr-n)   |
| 15     | 09482-00457 | Spark Plug (denso,u24esr-n)   |
| 15     | 09482-00459 | Spark Plug (denso,u27esr-n)   |
| 16     | 17661-29F00 | Cover, Thermostat             |
| 17     | 17670-33400 | Thermostat, Washer            |
| 18     | 01547-06163 | Bolt                          |
| 19     | 13111-07G00 | Pipe, Intake                  |
| 20     | 09402-58208 | Clamp, Head                   |
| 21     | 09402-52208 | Clamp, Carb                   |
| 22     | 09103-10218 | Bolt (10x45)                  |
| 23     | 09159-10058 | Nut                           |




| Ref No | Part No         | Description      |
|--------|-----------------|------------------|
| 1      | 11210-29F20-0F0 | Cylinder         |
| 2      | 01421-06253     | Stud Bolt        |
| 3      | 08316-10063     | Nut              |
| 4      | 11241-29F11     | Gasket, Cylinder |
| 5      | 04211-13189     | Pin              |
| 6      | 11330-07G00     | Tank, Oil Return |
| 7      | 01547-06103     | Bolt             |
| 8      | 11332-07G00     | Hose, Breather   |
| 9      | 11333-07G00     | Hose, Breather   |
| 10     | 09401-15404     | Clip             |
| 11     | 11334-07G00     | Hose, Breather   |
| 12     | 09401-15101     | Clip             |




VIEW A


VIEW B



| Ref No | Part No     | Description                    |
|--------|-------------|--------------------------------|
| 1      | 11301-07810 | Crankcase Set                  |
| 2      | 04211-13189 | • Pin                          |
| 3      | 01547-06403 | • Bolt                         |
| 4      | 01547-06703 | • Bolt                         |
| 5      | 09248-10010 | • Plug, Oil Gallery            |
| 6      | 09168-10002 | • Gasket                       |
| 7      | 09493-28010 | • Jet, Oil Gallery Cylinder    |
| 8      | 09280-04004 | • O Ring                       |
| 9      | 11323-29F00 | • Separator, Oil No.1          |
| 10     | 11324-29F00 | • Separator, Oil No.2          |
| 11     | 09125-06086 | • Screw, Separator             |
| 12     | 09247-12011 | Plug, Oil Drain                |
| 13     | 09168-12002 | Gasket                         |
| 14     | 11451-29F00 | Pipe, Oil Inner No.1           |
| 15     | 11460-07G00 | Pipe, T/m Oil Inner No.2       |
| 16     | 09280-05004 | O Ring (d:1.9,id:4.8)          |
| 17     | 09280-07004 | O Ring (d:1.9,id:6.8)          |
| 18     | 09103-10110 | Bolt (10x100)                  |
| 19     | 09103-10136 | Bolt (10x180)                  |
| 20     | 11611-09F51 | Spacer, Engine Mounting (l:30) |
| 21     | 09159-10058 | Nut                            |




| Ref No | Part No         | Description               |
|--------|-----------------|---------------------------|
| 1      | 11341-07G00     | Cover, Clutch             |
| 2      | 11482-07G00     | Gasket, Clutch Cover      |
| 3      | 01550-08123     | Plug, Oil Gallery         |
| 4      | 09168-08008     | Gasket, Oil Gallery Plug  |
| 5      | 04211-09149     | Pin                       |
| 6      | 01547-06303     | Bolt                      |
| 7      | 09168-06023     | Gasket                    |
| 8      | 01547-06123     | Plug, Oil Gallery         |
| 9      | 09168-06023     | Gasket                    |
| 10     | 09247-12006     | Plug, Oil Gallery (12x10) |
| 11     | 09168-12002     | Gasket (12.1x16.2x1.2)    |
| 12     | 01550-06103     | Bolt, Oil Level           |
| 13     | 09168-06004     | Gasket (6.2x11x1.2)       |
| 14     | 11351-07G00     | Cover, Magneto            |
| 15     | 11483-07G00     | Gasket, Magneto Cover     |
| 16     | 04211-09149     | Pin                       |
| 17     | 01547-06303     | Bolt                      |
| 18     | 01547-06403     | Bolt                      |
| 19     | 09248-14011     | Plug, T.d.c.              |
| 20     | 09168-14002     | Gasket (13.8x18.8x0.4)    |
| 21     | 09259-36016-20H | Plug, Crank Hole          |
| 22     | 09280-33004     | O Ring (d:3.1,id:32.7)    |
| 23     | 11360-07G00     | Cover, Engine Sprocket    |
| 24     | 01547-06603     | Bolt                      |
| 25     | 09160-06126     | Washer (6.5x14x2)         |
| 26     | 11352-29F50     | Cover, Starter Idle Gear  |
| 27     | 09280-71004     | O Ring (d:2.6,id:69.6)    |
| 28     | 01547-06163     | Bolt                      |
| 29     | 27640-07G00     | Plate, Chain Guide        |




| Ref No | Part No         | Description               |
|--------|-----------------|---------------------------|
| 1      | 12200-07G00     | Crankshaft Assy           |
| 2      | 12160-29F01-0B0 | • . Rod, Connecting       |
| 3      | 12210-29F10     | • . Pin                   |
| 4      | 09263-35035-0B0 | • . Bearing               |
| 5      | 12221-07G00     | • . Crankshaft, Rh        |
| 6      | 12261-07G00     | • . Crankshaft, Lh        |
| 7      | 12661-29F00     | Gear, Balancer Drive      |
| 8      | 09261-05005     | Pin                       |
| 9      | 09262-30100     | Bearing                   |
| 10     | 09282-14003     | Oil Seal, Rh (14x24x6)    |
| 11     | 24742-18A00     | Retainer, Oil Seal Rh     |
| 12     | 02112-06123     | Screw                     |
| 13     | 12731-29F00     | Sprocket, Cam Chain Drive |
| 14     | 21111-29F00     | Gear, Primary Drive       |
| 15     | 09140-18012     | Nut                       |
| 16     | 09164-18008     | Washer                    |
| 17     | 09421-05002     | Key, Gear                 |
| 18     | 12111-29F00-0F0 | Piston                    |
| 19     | 12140-29F00     | Ring Set, Piston          |
| 20     | 12151-24F10     | Pin, Piston               |
| 21     | 09381-20004     | Circlip                   |







| Ref No | Part No     | Description                     |
|--------|-------------|---------------------------------|
| 1      | 12611-07G00 | Gear, Starter Idle No.1         |
| 2      | 09181-12130 | Washer                          |
| 3      | 08331-31126 | Circlip                         |
| 4      | 12615-07G00 | Pin                             |
| 5      | 12600-29F00 | Limiter Assy, Starter Idle Gear |
| 6      | 12618-31D01 | Bush                            |
| 7      | 08211-10221 | Washer                          |
| 8      | 12600-29810 | Clutch Set, Starter             |
| 9      | 09263-25049 | • . Bearing (25x31x19)          |
| 10     | 07130-06163 | Bolt                            |



| Ref No | Part No     | Description             |
|--------|-------------|-------------------------|
| 1      | 12651-29F00 | Balancer, Crank         |
| 2      | 09262-15030 | Bearing                 |
| 3      | 12666-29F10 | Gear, Driven            |
| 4      | 09261-05005 | Pin, Inner Race         |
| 5      | 09140-12038 | Nut (m12)               |
| 6      | 09181-12009 | Washer (12.2x47x1.6)    |
| 7      | 12669-29F00 | Race, Driven Gear Inner |
| 8      | 09202-04017 | Pin, Driven Gear        |
| 9      | 09440-09031 | Spring, Driven Gear     |




| Ref No | Part No         | Description                                                |
|--------|-----------------|------------------------------------------------------------|
| 1      | 12710-07G00     | Cam Shaft, Intake                                          |
| 2      | 12720-07G00     | Cam Shaft, Exhaust                                         |
| 3      | 12911-29F00     | Valve, Intake                                              |
| 4      | 12912-29F00     | Valve, Exhaust                                             |
| 5      | 12921-03G00     | Spring, Valve                                              |
| 6      | 12931-02F10     | Retainer, Spring                                           |
| 7      | 12932-24F00     | Cotter, Valve                                              |
| 8      | 12933-38400     | Seat, Spring                                               |
| 9      | 09289-05011     | Oil Seal (5x10x8.7)                                        |
| 10     | 12891-02F00     | Tappet                                                     |
| 11     | 12892-41C00-230 | Shim, Tappet (t:2.30)                                      |
| 11     | 12892-41C00-235 | Shim, Tappet (t:2.35)                                      |
| 11     | 12892-41C00-240 | Shim, Tappet (t:2.40)                                      |
| 11     | 12892-41C00-245 | Shim, Tappet (t:2.45)                                      |
| 11     | 12892-41C00-250 | Shim, Tappet (t:2.50)                                      |
| 11     | 12892-41C00-255 | Shim, Tappet (t:2.55)                                      |
| 11     | 12892-41C00-260 | Shim, Tappet (t:2.60)                                      |
| 11     | 12892-41C00-265 | Shim, Tappet (t:2.65)                                      |
| 11     | 12892-41C00-270 | Shim, Tappet (t:2.70)                                      |
| 11     | 12892-41C00-275 | Shim, Tappet (t:2.75)                                      |
| 11     | 12892-41C00-280 | Shim, Tappet (t:2.80)                                      |
| 11     | 12892-41C00-285 | Shim, Tappet (t:2.85)                                      |
| 11     | 12892-41C00-290 | Shim, Tappet (t:2.90)                                      |
| 11     | 12892-41C00-295 | Shim, Tappet (t:2.95)                                      |
| 11     | 12892-41C00-300 | Shim, Tappet (t:3.00)                                      |
| 11     | 12892-41C00-305 | Shim, Tappet (t:3.05)                                      |
| 11     | 12892-41C00-310 | Shim, Tappet (t:3.10)                                      |
| 11     | 12892-41C00-315 | Shim, Tappet (t:3.15)                                      |
| 11     | 12892-41C00-320 | Shim, Tappet (t:3.20)                                      |
| 11     | 12892-41C00-325 | Shim, Tappet (t:3.25)                                      |
| 11     | 12892-41C00-330 | Shim, Tappet (t:3.30)                                      |
| 11     | 12892-41C00-335 | Shim, Tappet (t:3.35)                                      |
| 11     | 12892-41C00-340 | Shim, Tappet (t:3.40)                                      |
| 11     | 12892-41C00-345 | Shim, Tappet (t:3.45)                                      |
| 11     | 12892-41C00-350 | Shim, Tappet (t:3.50)                                      |
| 12     | 12800-41810     | Shim Set, Tappet Inc.ref.no.11-5~11-25 (5pcs.each) & No.13 |
| 13     | 99000-69471     | • . Case, Tappet Shim                                      |




| Ref No | Part No     | Description                    |
|--------|-------------|--------------------------------|
| 1      | 12760-29F00 | Chain, Cam Shaft Drive         |
| 2      | 12771-29F00 | Guide, Cam Chain No.1          |
| 3      | 12782-29F00 | Guide, Cam Chain No.2          |
| 4      | 12811-07G00 | Tensioner, Cam Chain           |
| 5      | 12812-35C00 | Bolt                           |
| 6      | 08211-06181 | Washer                         |
| 7      | 12830-07G00 | Adjuster Assy, Tensioner       |
| 8      | 12837-24F10 | • . Gasket                     |
| 9      | 12833-05A00 | • . Plug                       |
| 10     | 12831-39F00 | • . Spring                     |
| 11     | 12837-24A10 | Gasket, Adjuster               |
| 12     | 07130-06253 | Bolt                           |
| 13     | 12773-24F00 | Retainer, Cam Chain Guide No.1 |
| 14     | 09126-06011 | Screw                          |






| Ref No | Part No     | Description             |
|--------|-------------|-------------------------|
| 1      | 13200-07G01 | Carburetor Assy         |
| 1      | 13200-07G11 | Carburetor Assy         |
| 2      | 13291-29FA0 | . . Washer              |
| 3      | 13387-13F00 | . . Ring                |
| 4      | 13394-17E60 | . . E Ring              |
| 5      | 13503-07G00 | . . Spring              |
| 6      | 09280-05004 | . . O Ring              |
| 7      | 13418-33E00 | . . Holder              |
| 8      | 13507-07G00 | . . Diaphragm           |
| 9      | 13501-29FA0 | . . Piston Valve        |
| 10     | 13504-14E00 | . . Ring                |
| 11     | 13481-04F00 | . . Spring              |
| 12     | 13382-19E00 | . . Washer              |
| 13     | 13383-07G00 | . . Jet Needle (5e26-1) |
| 14     | 13295-29900 | . . O Ring              |
| 15     | 13291-29900 | . . Washer              |
| 16     | 13279-20B00 | . . Adjuster            |
| 17     | 13268-48700 | . . Spring              |
| 18     | 09491-26016 | . . Main Jet (#130)     |
| 19     | 13331-07G10 | . . Ring                |
| 20     | 13342-07G10 | . . Jet Holder          |
| 21     | 09493-33002 | . . Jet                 |
| 22     | 13254-01010 | . . Pin                 |
| 23     | 13370-07G00 | . . Needle Valve Assy   |
| 24     | 13258-04F00 | . . O Ring              |
| 25     | 13341-07G00 | . . Needle Jet (p-0m)   |
| 26     | 13411-07G00 | . . Plunger Assy        |
| 27     | 13417-07F00 | . . Spring              |
| 28     | 13278-47090 | . . O Ring              |
| 29     | 13681-04010 | . . Cap                 |
| 30     | 13418-07G10 | . . Guide Holder        |
| 31     | 13502-08F00 | . . Diaphragm Cover     |
| 32     | 13480-10F00 | . . Diaphragm Assy      |
| 33     | 13502-10F00 | . . Cover Assy          |
| 34     | 13481-41F20 | . . Spring              |
| 35     | 13601-04148 | . . Screw               |
| 36     | 13247-33E00 | . . Screw               |
| 37     | 02112-04107 | . . Screw               |
| 38     | 13247-13A00 | . . Screw               |
| 39     | 02112-04083 | . . Screw               |
| 40     | 13602-05A10 | . . Screw               |
| 41     | 13250-04F00 | . . Float Assy          |
| 42     | 09492-22014 | . . Pilot Jet (#22.5)   |
| 43     | 13356-27A00 | . . Pipe                |
| 44     | 02112-04063 | . . Screw               |
| 45     | 13673-20B00 | . . O Ring              |
| 46     | 13502-02C10 | . . Cover               |
| 47     | 13607-98410 | . . Nut                 |
| 48     | 09491-60005 | . . Starter Jet (#60.0) |
| 49     | 13686-07G00 | . . Hose                |
| 50     | 13268-03110 | . . Spring              |
| 51     | 13615-05G00 | . . Washer              |
| 52     | 13267-07G00 | . . Adjust Screw Assy   |
| 53     | 13602-05108 | . . Screw               |
| 54     | 13579-05G00 | . . Cable Guide         |




| Ref No | Part No         | Description            |
|--------|-----------------|------------------------|
| 55     | 13295-33010     | • O Ring               |
| 56     | 13684-07G00     | • Hose                 |
| 57     | 09352-50903-600 | • Hose                 |
| 58     | 13357-36A00     | • Plug                 |
| 59     | 13281-05A00     | • Plug                 |
| 60     | 09404-06429     | Clamp, Carb Drain Hose |




| Ref No | Part No     | Description                 |
|--------|-------------|-----------------------------|
| 1      | 13700-07G00 | Cleaner Assy, Air           |
| 2      | 13780-07G00 | • . Filter                  |
| 3      | 13791-03G00 | • . Holder                  |
| 4      | 13792-03G00 | • . Stopper, Holder         |
| 5      | 02142-06163 | • . Screw                   |
| 6      | 13881-07G00 | • . Tube, Outlet            |
| 7      | 13858-14D20 | • . Joint                   |
| 8      | 13859-41B10 | • . Plug, Breather          |
| 9      | 09401-14301 | • . Clip                    |
| 10     | 09402-82208 | • . Clamp (cleaner Side)    |
| 11     | 09402-64203 | • . Clamp (carburetor Side) |
| 12     | 13810-07G00 | • . Trap, Flame             |
| 13     | 13740-07G00 | • . Cap, Air Cleaner        |
| 14     | 13746-07G00 | • . Gasket                  |
| 15     | 13891-07G00 | • . Joint, Inlet            |
| 16     | 13896-07G00 | • . Duct, Inlet             |
| 17     | 09402-56208 | • . Clamp                   |
| 18     | 01550-06163 | Bolt, Air Cleaner Rh        |
| 19     | 01547-06203 | Bolt, Air Cleaner Lh        |






| Ref No | Part No     | Description                 |
|--------|-------------|-----------------------------|
| 1      | 14150-07G00 | Pipe, Exhaust               |
| 2      | 14181-29E02 | Gasket, Exhaust Pipe        |
| 3      | 01421-08253 | Stud Bolt                   |
| 4      | 08319-31083 | Nut                         |
| 5      | 14180-07G00 | Cover, Exhaust Pipe         |
| 6      | 14771-07G00 | Connector, Muffler          |
| 7      | 14310-07G10 | Body, Muffler               |
| 8      | 14459-07G00 | • . Clamp                   |
| 9      | 07120-08403 | • . Bolt                    |
| 10     | 14424-07G01 | • . Spacer                  |
| 11     | 14773-29F00 | • . Gasket                  |
| 12     | 14850-07G10 | • . Arrester                |
| 13     | 09106-06076 | • . Bolt                    |
| 14     | 09160-08503 | Washer                      |
| 15     | 09180-08152 | Spacer                      |
| 16     | 09320-12071 | Cushion                     |
| 17     | 07120-08403 | Bolt                        |
| 18     | 09139-06109 | Screw, Exhaust Pipe Cover   |
| 19     | 14184-07G00 | Washer, Exhaust Pipe Cover  |
| 20     | 14185-07G00 | Spacer, Exhaust Pipe Cover  |
| 21     | 09320-08069 | Cushion, Exhaust Pipe Cover |






| Ref No | Part No     | Description                |
|--------|-------------|----------------------------|
| 1      | 16400-29F00 | Pump Assy, Engine Oil No.1 |
| 2      | 16331-29F01 | Gear, Driven               |
| 3      | 09261-04009 | Pin                        |
| 4      | 09181-10158 | Washer                     |
| 5      | 08331-31106 | Circlip                    |
| 6      | 02122-06253 | Screw                      |
| 7      | 16410-29F00 | Rotor Set, Oil Pump No.2   |
| 8      | 16520-29F00 | Strainer, Oil Pump         |
| 9      | 01550-06253 | Bolt                       |
| 10     | 16510-29F00 | Filter, Engine Oil         |
| 11     | 09280-13004 | O Ring (d:1.9,id:13.0)     |
| 12     | 16512-47E00 | Cap, Oil Filter            |
| 13     | 09280-54001 | O Ring (d:2.4,id:52.6)     |
| 14     | 09440-18002 | Spring                     |
| 15     | 01547-06163 | Bolt                       |
| 16     | 09440-07073 | Spring                     |
| 17     | 06111-12004 | Ball                       |
| 18     | 16442-29F00 | Seat, Oil Check Valve      |
| 19     | 16321-29F00 | Gear, Oil Pump Idle        |
| 20     | 16322-29F00 | Shaft                      |
| 21     | 08331-31126 | Circlip                    |




| Ref No | Part No         | Description               |
|--------|-----------------|---------------------------|
| 1      | 16460-07G00     | Hose, Oil Tank Rh         |
| 2      | 16470-07G00     | Hose, Oil Tank Lh         |
| 3      | 09360-14012     | Bolt, Union (14x27)       |
| 4      | 09168-14015     | Gasket, Oil Hose Union    |
| 5      | 07120-06203     | Bolt, Upper               |
| 6      | 07120-06203     | Bolt                      |
| 7      | 09280-11005     | O Ring, Oil Hose          |
| 8      | 04211-11129     | Pin, Oil Tank Hose        |
| 9      | 16480-07G00     | Hose, Oil Overflow        |
| 10     | 09401-12403     | Clip                      |
| 11     | 11971-07G00     | Gauge, Oil Level          |
| 12     | 09280-17003     | O Ring, Oil Level Gauge   |
| 13     | 01550-08123     | Plug, Oil Drain           |
| 14     | 09168-08008     | Gasket, Oil Drain Plug    |
| 15     | 16410-07G00     | Tank, Oil                 |
| 16     | 09118-06097     | Bolt, Oil Tank            |
| 17     | 09320-10042     | Cushion, Oil Tank         |
| 18     | 09180-06290     | Spacer, Oil Tank          |
| 19     | 68322-07G00     | Note, Engine Oil (2000ml) |
| 20     | 16421-07G00     | Protector, Oil Tank       |
| 21     | 09409-06322-5PK | Clip                      |
| 22     | 51553-42AA0     | Cushion, Oil Tank         |





| Ref No | Part No     | Description             |
|--------|-------------|-------------------------|
| 1      | 17400-29F00 | Pump Assy, Water        |
| 2      | 17491-29F00 | • Impeller/shaft        |
| 3      | 17470-02F10 | • Seal, Mechanical      |
| 4      | 17419-29F00 | • Oil Seal              |
| 5      | 08110-69000 | • Bearing               |
| 6      | 08332-11086 | • E Ring                |
| 7      | 17435-33400 | • O Ring                |
| 8      | 17410-29F21 | Case, Water Pump        |
| 9      | 17435-29F00 | O Ring                  |
| 10     | 01547-06103 | Bolt, Drain             |
| 11     | 09168-06004 | Gasket (6.2x11x1.2)     |
| 12     | 09103-06204 | Bolt (6x30)             |
| 13     | 09103-06209 | Bolt                    |
| 14     | 09280-22001 | O Ring (d:2.4,id:21.8)  |
| 15     | 08331-31106 | Circlip                 |
| 16     | 17461-29F00 | Gear, Water Pump Driven |
| 17     | 09181-10158 | Washer                  |
| 18     | 09261-04001 | Pin                     |

| Ref No | Part No     | Description             |
|--------|-------------|-------------------------|
| 1      | 17710-07G10 | Radiator Assy, Water    |
| 2      | 17760-07G00 | Cover, Radiator         |
| 3      | 09118-06097 | Bolt                    |
| 4      | 09180-06290 | Spacer                  |
| 5      | 09320-10042 | Cushion                 |
| 6      | 17680-50F70 | Switch, Radiator Fan    |
| 7      | 17689-50F00 | • O Ring                |
| 8      | 17800-07G10 | Fan Assy, Radiator      |
| 8a     | 17820-07G10 | Boot                    |
| 9      | 17802-14F00 | Nut                     |
| 10     | 01550-06103 | Bolt                    |
| 11     | 34850-07G00 | Switch Assy, Water Temp |




| Ref No | Part No     | Description             |
|--------|-------------|-------------------------|
| 1      | 17851-07G00 | Hose, Radiator Inlet    |
| 2      | 17852-07G00 | Hose, Radiator Outlet   |
| 3      | 09402-32511 | Clamp                   |
| 4      | 17910-07G00 | Tank Assy, Reservoir    |
| 5      | 17931-02FA0 | • . Cap, Reservoir Tank |
| 6      | 09116-06168 | Screw                   |
| 7      | 17981-45C00 | Hose, Inlet             |
| 8      | 09401-08411 | Clip                    |
| 9      | 17981-19F00 | Hose, Overflow          |
| 10     | 17730-14G00 | Cap                     |






| Ref No | Part No     | Description                |
|--------|-------------|----------------------------|
| 1      | 21200-07G00 | Gear Assy, Primary Driven  |
| 2      | 08211-22425 | Washer                     |
| 3      | 21251-29F00 | Spacer, Primary Driven     |
| 4      | 21410-07G00 | Hub, Sleeve                |
| 5      | 21441-29F00 | Plate, Drive No.1          |
| 6      | 21442-29F00 | Plate, Drive No.2          |
| 7      | 21451-44D00 | Plate, Driven              |
| 8      | 21462-29F00 | Disc, Pressure             |
| 9      | 21413-29F00 | Spring                     |
| 10     | 07130-06303 | Bolt                       |
| 11     | 21414-29F00 | Washer                     |
| 12     | 09262-12001 | Bearing, Pressure Disk     |
| 13     | 09140-20001 | Nut                        |
| 14     | 09167-22021 | Lock Washer                |
| 15     | 23110-07G00 | Rod, Clutch Push           |
| 16     | 23117-05200 | Retainer, Cl Rlse Oil Seal |
| 17     | 23121-29F00 | Piece, Cl Rlse             |
| 18     | 23122-29F00 | Cam Shaft, Cl Rlse         |
| 19     | 23271-20902 | Arm, Cl Rlse               |
| 20     | 09181-10195 | Washer, Cl Rlse            |
| 21     | 09263-10014 | Bearing, Cl Rlse Low       |
| 22     | 09263-12024 | Bearing, Cl Rlse Up        |
| 23     | 09282-10012 | Seal, Cl Rlse Arm          |
| 24     | 01547-06163 | Bolt, Cl Rlse Arm          |
| 25     | 02142-06103 | Stopper, Cl Rlse Cam Shaft |




| Ref No | Part No         | Description                    |
|--------|-----------------|--------------------------------|
| 1      | 24120-07G00     | Shaft, Counter (nt:13)         |
| 2      | 24221-07G00     | Gear, 2nd Drive (nt:18)        |
| 3      | 24231-07G00     | Gear, 3rd Drive (nt:21)        |
| 4      | 24241-07G00     | Gear, 4th Drive (nt:23)        |
| 5      | 24251-07G00     | Gear, 5th Drive (nt:26)        |
| 6      | 09167-25012     | Washer, 4th                    |
| 7      | 09181-17223     | Washer, 2nd (17x30x1.0)        |
| 8      | 09181-25139     | Washer, 5th (25x32x1.0)        |
| 9      | 09262-17027     | Bearing, Cntr Shaft Lh         |
| 10     | 09380-25003     | Circlip, 4th/5th Drive         |
| 11     | 09262-25122     | Bearing, Cntr Shaft Rh         |
| 12     | 24130-07G00     | Drive Shaft                    |
| 13     | 24311-07G00     | Gear, 1st Driven (nt:33)       |
| 14     | 24321-07G00     | Gear, 2nd Driven (nt:30)       |
| 15     | 24331-07G00     | Gear, 3rd Driven (nt:26)       |
| 15a    | 24332-24510     | Bush, Reverse Driven           |
| 16     | 24341-07G00     | Gear, 4th Driven (nt:23)       |
| 17     | 24351-07G00     | Gear, 5th Driven (nt:22)       |
| 18     | 24571-07G01     | Gear, Reverse Driven (nt:28)   |
| 19     | 24581-07G00     | Dog, Reverse                   |
| 20     | 29215-07G00     | Bush, 3rd Driven               |
| 21     | 09167-25016     | Washer, 3rd Driven             |
| 22     | 09167-25016     | Washer, Reverse Driven         |
| 23     | 09181-17223     | Washer, 1st Driven Rh          |
| 24     | 09181-20195     | Washer, 1st Driven Lh          |
| 25     | 09181-25167     | Washer, 2nd Driven             |
| 26     | 09262-25125     | Bearing, Drive Shaft Lh        |
| 27     | 09283-25086     | Seal, Drive Shaft Oil          |
| 28     | 09300-20033     | Bush, 1st Driven               |
| 29     | 09300-25020     | Bush, 2nd Driven               |
| 30     | 09380-25003     | Circlip, 2nd/3rd Driven        |
| 31     | 09380-25003     | Circlip, Reverse Driven        |
| 32     | 09262-17023     | Bearing, Drive Shaft Rh        |
| 33     | 24741-05G00     | Retainer, Counter Shaft Rh     |
| 34     | 09126-06011     | Screw (6x12)                   |
| 35     | 24751-07G00     | Retainer, Drive Shaft Oil Seal |
| 36     | 09126-06007     | Bolt, Retainer                 |
| 37     | 24551-05G00     | Shaft, Reverse Idle            |
| 38     | 24561-07G00     | Gear, Reverse Idle (nt:24)     |
| 39     | 24562-05G00     | Bush, Reverse                  |
| 40     | 09181-17195     | Washer (17x28x1.0)             |
| 41     | 09181-17021     | Washer (17x36x1.0)             |
| 42     | 09164-22011     | Wave Washer                    |
| 43     | 08331-31176     | Circlip                        |
| 44     | 27511-07G00     | Sprocket, Engine (nt:14)       |
| 45     | 27512-07G00     | Plate, Sprocket                |
| 46     | 27600-29F10-112 | Chain Assy (rk520kz0,112l)     |
| 47     | 27620-29F10     | • Joint Set                    |
| 48     | 09111-06039     | Bolt                           |




| Ref No | Part No     | Description                    |
|--------|-------------|--------------------------------|
| 1      | 25211-07G00 | Fork, Gear Shift No.1          |
| 2      | 25221-07G00 | Fork, Gear Shift No.2          |
| 3      | 25231-07G00 | Fork, Gear Shift No.3          |
| 4      | 25411-07G00 | Shaft, Gear Fork No.1          |
| 5      | 24741-21A00 | Retainer, Shift Cam Brg        |
| 6      | 25310-07G00 | Cam, Gear Shift                |
| 7      | 04221-04089 | • . Pin, Shift Cam             |
| 8      | 25313-27C02 | Pin, Shift                     |
| 9      | 25320-07G00 | Shaft, Reverse Lock            |
| 10     | 25322-36E00 | Shifter, Gear Shift Cam        |
| 11     | 25323-34201 | Pawl, Gear Shift No.1          |
| 12     | 25324-34201 | Pawl, Gear Shift No.2          |
| 13     | 25328-07G00 | Spring, Reverse Lock           |
| 14     | 25331-37E10 | Lifter, Gear Shift Pawl        |
| 15     | 09180-07014 | Roller, Gear Cam Shifter       |
| 16     | 09261-05003 | Pin, Shift Pole (5x8)          |
| 17     | 09263-25018 | Bearing, Shift Cam Lh          |
| 18     | 09283-10010 | Seal, Reverse Lock             |
| 19     | 09440-04003 | Spring, Shift Pawl Return      |
| 20     | 09125-06110 | Screw, Shift Cam Brg           |
| 21     | 09126-06011 | Screw, Shift Pawl Lifter       |
| 22     | 08113-69050 | Bearing, Shift Cam Rh          |
| 23     | 25350-07G00 | Stopper, Shift Cam             |
| 24     | 25381-36E11 | Plate, Shift Cam Stopper       |
| 25     | 09111-06041 | Bolt, Cam Stopper Arm          |
| 26     | 25355-07G00 | Spring, Shift Cam              |
| 27     | 08211-06121 | Washer, Shift Cam              |
| 28     | 25510-07G00 | Shaft, Gear Shift              |
| 29     | 25671-38B00 | Stopper, Gear Shift Arm        |
| 30     | 09283-14006 | Seal, Shift Shaft Oil          |
| 31     | 09444-20006 | Spring, Shift Shaft Return     |
| 32     | 09181-14139 | Washer, Gear Shaft             |
| 33     | 08331-31146 | Circlip, Gear Shaft            |
| 34     | 09160-14046 | Washer, Gear Shift Lh          |
| 35     | 09263-14027 | Bearing, Gear Shaft (14x20x12) |
| 35a    | 09180-14016 | Spacer (14x20x17.5)            |
| 36     | 25600-07G01 | Lever Assy, Gear Shift         |
| 37     | 25652-16500 | • . Rubber, Gear Pedal         |
| 38     | 01550-06203 | Bolt, Gear Shift               |
| 39     | 37720-07G00 | Base Assy, Gear Shift Term     |
| 40     | 09209-05011 | Contact                        |
| 41     | 09280-26005 | O Ring (d:2.4,id:26.2)         |
| 42     | 09440-04010 | Spring                         |
| 43     | 07120-05163 | Bolt                           |







| Ref No | Part No     | Description                |
|--------|-------------|----------------------------|
| 1      | 31100-29F00 | Motor Assy,starting        |
| 2      | 31130-13E00 | • . Brush Terminal Set     |
| 3      | 31143-49040 | • . O Ring                 |
| 4      | 31132-13E00 | • . Brush Holder Set       |
| 5      | 31135-31300 | • . Brush Spring           |
| 6      | 31264-13E00 | • . O Ring                 |
| 7      | 31170-19B10 | • . Washer Set             |
| 8      | 31280-19F00 | • . Set Bolt               |
| 9      | 31156-13E00 | •• .. O Ring               |
| 10     | 09280-24003 | • . O Ring (d:3.0,id:24.5) |
| 11     | 01547-06253 | Bolt                       |
| 12     | 08361-35068 | Nut, Starting Motor        |

| Ref No | Part No     | Description              |
|--------|-------------|--------------------------|
| 1      | 32101-07G00 | Stator Assy              |
| 2      | 32102-07G00 | Rotor Assy               |
| 3      | 32371-13E00 | Clamp, Magneto Lead No.1 |
| 4      | 07130-05123 | Bolt, Pulser/clamp       |
| 5      | 07130-05253 | Bolt, Stator             |
| 6      | 31792-07G00 | Nut, Magneto Rotor       |
| 7      | 09420-04008 | Key                      |




| Ref No | Part No     | Description                |
|--------|-------------|----------------------------|
| 1      | 31800-07G00 | Relay Assy, Starting Motor |
| 2      | 31861-07G00 | • . Cover                  |
| 3      | 09481-20101 | • . Fuse (20a)             |
| 4      | 09128-06013 | Bolt, Starting Motor (6x8) |
| 5      | 32800-05F10 | Rectifier Assy             |
| 6      | 02162-06203 | Bolt, Rectifier            |
| 7      | 32900-07G00 | Cdi Unit                   |
| 8      | 33410-09F00 | Coil Assy, Ignition        |
| 9      | 01550-06163 | Bolt                       |
| 10     | 33510-48B10 | Cap Assy, Spark Plug       |
| 11     | 33541-23E01 | Seal, Spark Plug Cap       |
| 12     | 33542-38B00 | Seal, High Tension Cord    |
| 13     | 33543-33E01 | Cover, Spark Plug Cap      |






| Ref No | Part No     | Description            |
|--------|-------------|------------------------|
| 1      | 33610-32C10 | Battery Assy (12v,8ah) |
| 2      | 33652-03G00 | Protector (20x50x11)   |
| 3      | 33652-28010 | Protector (20x45x6)    |
| 4      | 33652-41B00 | Protector (27x80x3)    |
| 5      | 33652-07G00 | Protector, Battery     |
| 6      | 33810-07G00 | Wire, Starter Motor    |
| 7      | 31861-48B10 | • . Cap, Starter Motor |
| 8      | 33820-07G00 | Wire, Battery Plus     |
| 9      | 33624-10D00 | • . Cap, Battery Plus  |
| 10     | 33860-07G00 | Wire, Battery Minus    |





| Ref No | Part No         | Description               |
|--------|-----------------|---------------------------|
| 1      | 35100-07G00-YU1 | Headlamp Assy (yellow)    |
| 1      | 35100-07G00-30H | Headlamp Assy (white)     |
| 2      | 35143-07G00-YU1 | • . Molding (yellow)      |
| 2      | 35143-07G00-30H | • . Molding (white)       |
| 3      | 35171-07G00     | • . Socket/cord Assy      |
| 4      | 03511-04123     | • . Screw                 |
| 5      | 09471-12097     | Bulb (14v30/30w)          |
| 6      | 09139-06118     | Screw, Headlamp           |
| 7      | 09320-10501     | Cushion                   |
| 8      | 02162-06163     | Bolt, Headlamp Adjust     |
| 9      | 35950-14A00     | Reflex Reflector Assy, Fr |
| 10     | 35956-07G01     | Bracket, Fr Side Rh       |
| 10     | 35957-07G01     | Bracket, Fr Side Lh       |

| Ref No | Part No     | Description            |
|--------|-------------|------------------------|
| 1      | 35710-03G00 | Lamp Assy, Rear Comb   |
| 2      | 35718-03G00 | • . Socket & Cord Assy |
| 3      | 09471-12083 | • . Bulb (12v,21/5w)   |
| 4      | 09320-06023 | Cushion                |
| 5      | 35726-07G00 | Bracket, Rear Comb     |
| 6      | 33652-05G20 | Cushion (12x17x17)     |
| 7      | 33652-07G10 | Cushion (6x17x17)      |




| Ref No | Part No     | Description            |
|--------|-------------|------------------------|
| 1      | 35710-03G00 | Lamp Assy, Rear Comb   |
| 2      | 35718-03G00 | • . Socket & Cord Assy |
| 3      | 09471-12083 | • . Bulb (12v,21/5w)   |
| 4      | 09320-06023 | Cushion                |
| 5      | 33652-05G20 | Cushion (12x17x17)     |
| 6      | 33652-07G10 | Cushion (6x17x17)      |






| Ref No | Part No     | Description               |
|--------|-------------|---------------------------|
| 1      | 35710-03G00 | Lamp Assy, Rear Comb      |
| 2      | 35718-03G00 | • . Socket/cord Assy      |
| 3      | 09471-12083 | • . Bulb (12v,21/5w)      |
| 4      | 09320-06023 | Cushion                   |
| 5      | 35726-07G10 | Bracket, Rear Comb        |
| 6      | 35970-14A10 | Reflector Assy, Rear Side |
| 7      | 35975-07G00 | Bracket, Rear Side Rr Rh  |
| 8      | 02142-06163 | Screw, Rr Side Rr Bkt     |
| 9      | 08316-10053 | Nut, Rr Side Rr           |
| 10     | 08316-10063 | Nut, Rr Side Rr Bkt       |
| 11     | 33652-05G20 | Cushion (12x17x17)        |
| 12     | 33652-07G10 | Cushion (6x17x17)         |
| 13     | 35970-07F00 | Reflector Assy, Rear      |
| 14     | 08316-10053 | Nut                       |







| Ref No | Part No     | Description               |
|--------|-------------|---------------------------|
| 1      | 35710-03G00 | Lamp Assy, Rear Comb      |
| 2      | 35718-03G00 | • . Socket/cord Assy      |
| 3      | 09471-12083 | • . Bulb (12v,21/5w)      |
| 4      | 09320-06023 | Cushion                   |
| 5      | 33652-05G20 | Cushion (12x17x17)        |
| 6      | 33652-07G10 | Cushion (6x17x17)         |
| 7      | 35970-14A10 | Reflector Assy, Rear Side |
| 8      | 35975-07G00 | Bracket, Rear Side Rr Rh  |
| 9      | 08316-10053 | Nut, Rr Side Rr           |
| 10     | 35726-07G20 | Bracket, Rear Rr          |
| 11     | 35970-07F00 | Reflector Assy, Rr        |
| 12     | 02162-06163 | Screw, Rr Bkt             |
| 13     | 08316-10053 | Nut                       |




| Ref No | Part No     | Description                |
|--------|-------------|----------------------------|
| 1      | 36380-07G00 | Lamp Assy, Pilot           |
| 2      | 34173-26F00 | • . Socket                 |
| 3      | 34178-26F00 | • . Ring                   |
| 4      | 36321-05G00 | • . Lens, Neutral (green)  |
| 5      | 36329-05G00 | • . Lens, Reverse (red)    |
| 6      | 36361-05G00 | • . Lens, Water Temp (red) |
| 7      | 09471-12103 | • . Bulb (14v,3w,t6.5)     |



| Ref No | Part No     | Description            |
|--------|-------------|------------------------|
| 1      | 36610-07G00 | Harness, Wiring        |
| 2      | 09403-20403 | Clamp                  |
| 3      | 09404-06435 | Clamp (l:135)          |
| 4      | 09407-03401 | Clamp (l:33)           |
| 5      | 09407-11402 | Clamp (l:90)           |
| 6      | 09407-12402 | Clamp (l:120)          |
| 7      | 09407-14403 | Clamp (l:125)          |
| 8      | 37110-07G00 | Switch Assy, Ignition  |
| 9      | 37740-07G00 | Switch Assy, Stop Lamp |
| 10     | 09443-06073 | Spring                 |
| 11     | 37146-19B00 | Key, Blank (type:c)    |
| 11     | 37146-19B10 | Key, Blank (type:d)    |
| 11     | 37146-19B20 | Key, Blank (type:e)    |
| 11     | 37146-19B30 | Key, Blank (type:f)    |





| Ref No | Part No     | Description                |
|--------|-------------|----------------------------|
| 1      | 36610-07G10 | Harness, Wiring            |
| 2      | 09407-05411 | • . Clamp                  |
| 3      | 09407-17403 | • . Clamp                  |
| 4      | 09403-20403 | Clamp                      |
| 5      | 09404-06435 | Clamp (l:135)              |
| 6      | 09407-03401 | Clamp (l:33)               |
| 7      | 09407-11402 | Clamp (l:90)               |
| 8      | 09407-12402 | Clamp (l:120)              |
| 9      | 09407-14403 | Clamp (l:125)              |
| 10     | 36740-19B10 | Box Assy, Cooling Fan Fuse |
| 11     | 09481-10101 | • . Fuse (10a)             |
| 12     | 37110-07G00 | Switch Assy, Ignition      |
| 13     | 37740-07G00 | Switch Assy, Stop Lamp     |
| 14     | 09443-06073 | Spring                     |
| 15     | 37146-19B00 | Key, Blank (type:c)        |
| 15     | 37146-19B10 | Key, Blank (type:d)        |
| 15     | 37146-19B20 | Key, Blank (type:e)        |
| 15     | 37146-19B30 | Key, Blank (type:f)        |




| Ref No | Part No         | Description           |
|--------|-----------------|-----------------------|
| 1      | 41100-07G10-YU8 | Frame (gray)          |
| 2a     | 41200-07G10-YD8 | Rail, Seat (silver)   |
| 2a     | 41200-07G20-YD8 | Rail, Seat (silver)   |
| 3      | 09103-08266     | Bolt, Upper           |
| 4      | 09103-10293     | Bolt, Lower           |
| 5      | 41911-07G00     | Plate, Mount Front Rh |
| 6      | 41912-07G00     | Plate, Mount Front Lh |
| 7      | 01550-08203     | Bolt                  |
| 8      | 41990-07G00     | Plate, Mount Upper    |
| 9      | 01550-08163     | Bolt                  |
| 10     | 42511-07G00     | Protector, Engine     |
| 11     | 09111-06063     | Bolt                  |
| 12     | 41560-07G00     | Plate, Battery        |
| 13     | 01550-06163     | Bolt                  |
| 14     | 43910-37F00     | Roller, Chain Control |
| 15     | 09103-08083     | Bolt                  |
| 16     | 09181-08111     | Washer                |
| 17     | 43978-24500     | Cap, Seat Rail        |

| Ref No | Part No     | Description    |
|--------|-------------|----------------|
| 1      | 43110-07G10 | Pedal, Brake   |
| 2      | 09280-14011 | O Ring         |
| 3      | 01550-06653 | Bolt           |
| 4      | 09160-06138 | Washer         |
| 5      | 08319-21063 | Nut            |
| 6      | 09443-12019 | Spring, Return |






| Ref No | Part No         | Description            |
|--------|-----------------|------------------------|
| 1      | 43510-07G10     | Footrest, Rh           |
| 2      | 43520-07G10     | Footrest, Lh           |
| 3      | 09103-10275     | Bolt                   |
| 4      | 43570-07G10     | Reinforce, Mudguard Rh |
| 5      | 43580-07G10     | Reinforce, Mudguard Lh |
| 6      | 09103-08266     | Bolt                   |
| 7      | 43990-07G00-YD8 | Grip, Front (silver)   |
| 8      | 01550-08163     | Bolt                   |
| 9      | 43980-07G10-YD8 | Grip, Rear (silver)    |
| 10     | 01550-08203     | Bolt                   |




| Ref No | Part No         | Description                |
|--------|-----------------|----------------------------|
| 1      | 44100-07G00     | Tank Assy, Fuel            |
| 2      | 44200-29F00     | Cap Assy, Fuel Tank        |
| 3      | 09352-50823-600 | Hose, Breather (1:600->90) |
| 4      | 44425-20E00     | Hose, Breather No.2        |
| 5      | 44511-03G00     | Cushion, Front             |
| 6      | 44542-07G00     | Cushion, Side              |
| 7      | 09407-14407     | Clamp                      |
| 8      | 09160-06136     | Washer, Seat Hook          |
| 9      | 09180-06286     | Spacer                     |
| 10     | 02142-06203     | Screw                      |
| 11     | 44281-03G00     | Cushion, Rear              |
| 12     | 09180-06293     | Spacer                     |
| 13     | 09116-06190     | Bolt                       |
| 14     | 44300-07G00     | Cock Assy, Fuel            |
| 15     | 44420-07G00     | Hose, Fuel                 |
| 16     | 09401-11407     | Clip                       |
| 17     | 01547-06163     | Bolt                       |
| 18     | 09168-06026     | Gasket                     |
| 19     | 47150-07G00     | Cover, Cleaner Inlet Duct  |







| Ref No | Part No         | Description             |
|--------|-----------------|-------------------------|
| 1      | 53111-07G00-YU1 | Fender, Front (yellow)  |
| 1      | 53111-07G00-30H | Fender, Front (white)   |
| 2      | 53118-07G01     | Fender, Front Lower     |
| 3      | 09409-07333     | Clip                    |
| 4      | 09111-06063     | Bolt                    |
| 5      | 09148-05038     | Nut                     |
| 6      | 03541-05163     | Screw                   |
| 7      | 09320-11008     | Cushion                 |
| 8      | 09169-06074     | Spacer                  |
| 9      | 01550-06253     | Bolt                    |
| 10     | 53210-07G00     | Bracket, Rh             |
| 11     | 53220-07G00     | Bracket, Lh             |
| 12     | 09103-06083     | Bolt                    |
| 13     | 09321-06033     | Cushion                 |
| 14     | 53119-07G00-YU1 | Fender, Center (yellow) |
| 14     | 53119-07G00-30H | Fender, Center (white)  |
| 15     | 09409-07333     | Clip                    |
| 16     | 68111-01C20-GY8 | Emblem, "suzuki"        |
| 16     | 68111-01C20-8YM | Emblem, "suzuki"        |
| 17     | 68151-07G00-NA2 | Emblem, "quadsport"     |
| 17     | 68151-07G00-NN7 | Emblem, "quadsport"     |
| 18     | 68281-07G00     | Emblem, "s"             |

| Ref No | Part No         | Description             |
|--------|-----------------|-------------------------|
| 1      | 53112-07G00-YU1 | Cover, Side Rh (yellow) |
| 1      | 53112-07G00-019 | Cover, Side Rh (black)  |
| 2      | 53122-07G00-YU1 | Cover, Side Lh (yellow) |
| 2      | 53122-07G00-019 | Cover, Side Lh (black)  |
| 3      | 09409-07333     | Clip                    |
| 4      | 53145-07G00     | Cushion                 |
| 7      | 68155-07G20-KD2 | Tape, Side Rh           |
| 7      | 68155-07G20-YDS | Tape, Side Rh           |
| 8      | 68156-07G20-KD2 | Tape, Side Lh           |
| 8      | 68156-07G20-YDS | Tape, Side Lh           |







| Ref No | Part No         | Description             |
|--------|-----------------|-------------------------|
| 1      | 56111-07G10     | Handlebar               |
| 2      | 56171-07G00-GY8 | Cover, Steering Head    |
| 2      | 56171-07G00-60K | Cover, Steering Head    |
| 3      | 68721-05D00-GY8 | Emblem                  |
| 3      | 68721-05D00-8YM | Emblem                  |
| 4      | 09409-06314-5PK | Clip (black)            |
| 5      | 56411-07G00     | Bracket, Rh             |
| 6      | 56421-07G00     | Bracket, Lh             |
| 7      | 56200-07850     | Balancer Set, Handlebar |
| 8      | 09127-06018     | . . Screw               |
| 9      | 56272-23F00     | . . Expander            |
| 10     | 09160-06126     | . . Washer              |
| 11     | 56272-42F00     | . . Expander            |
| 12     | 56276-17D00     | . . Spacer              |
| 13     | 09159-06024     | . . Nut                 |
| 14     | 58200-07G00     | Cable, Clutch           |
| 15     | 58300-07G00     | Cable Assy, Throttle    |
| 16     | 58410-07G00     | Cable, Starter          |
| 17     | 09320-06503     | Washer                  |
| 18     | 58620-07G00     | Guide, Cable            |
| 19     | 09103-06092     | Bolt                    |
| 20     | 58810-07G10     | Cable, Parking Brake    |
| 21     | 58631-07G10     | Guide, Parking Cable    |
| 22     | 09403-14304     | Clamp                   |
| 23     | 58634-29F00     | Stopper, Cable          |
| 24     | 09403-07325     | Clamp                   |
| 25     | 09403-07327     | Clamp                   |
| 26     | 09407-14403     | Clamp, Cable            |




| Ref No | Part No     | Description            |
|--------|-------------|------------------------|
| 1      | 57900-07860 | Knob Set, Reverse Lock |
| 2      | 57940-07G00 | Bracket, Knob          |
| 3      | 03541-05203 | Screw                  |
| 4      | 02142-05203 | Screw                  |
| 5      | 08316-10053 | Nut                    |
| 6      | 58850-07G00 | Bracket, Reverse Cable |
| 7      | 02162-05103 | Bolt                   |
| 8      | 09408-00044 | Clip                   |




| Ref No | Part No         | Description                |
|--------|-----------------|----------------------------|
| 1      | 57211-22A01-291 | Grip (black)               |
| 2      | 57100-07G00     | Case Assy, Throttle        |
| 3      | 57121-07G00     | • . Cap                    |
| 4      | 57157-07G00     | • . Gasket                 |
| 5      | 57128-07G00     | • . Screw                  |
| 6      | 57126-07G00     | • . Holder                 |
| 7      | 57127-07G00     | • . Bolt                   |
| 8      | 08310-00053     | • . Nut                    |
| 9      | 02112-05203     | • . Screw                  |
| 10     | 57421-39D20     | Lever, Front Brake         |
| 11     | 57431-04F00     | Bolt, Pivot                |
| 12     | 57433-09F00     | Nut                        |
| 13     | 57460-17C00     | Switch Assy, Stop          |
| 14     | 57465-17C00     | • . Screw                  |
| 15     | 57211-22A01-291 | Grip (black)               |
| 16     | 37400-07G00     | Switch Assy, Handle Lh     |
| 17     | 37571-19B01     | • . Lever, Choke           |
| 18     | 37576-19B01     | • . Cover, Choke           |
| 19     | 02112-05457     | • . Screw                  |
| 20     | 02112-05407     | • . Screw                  |
| 21     | 57500-07G00     | Lever Set, Clutch          |
| 22     | 57621-07G00     | • . Lever                  |
| 23     | 57513-07G00     | • . Bolt, Pivot            |
| 24     | 57432-07G00     | • . Washer                 |
| 25     | 08319-21063     | • . Nut                    |
| 26     | 57512-07G00     | • . Holder                 |
| 27     | 01547-06203     | • . Bolt                   |
| 28     | 57442-07G00     | • . Nut, Adjuster          |
| 29     | 57441-45C00     | • . Bolt, Adjuster         |
| 30     | 57800-07850     | • . Lock Set, Parking Lock |
| 31     | 57431-07G00     | • . Bolt, Parking Lock     |
| 32     | 57433-07G00     | • . Washer                 |
| 33     | 57623-07G00     | • . Spacer                 |
| 34     | 08319-21063     | • . Nut                    |
| 35     | 57700-07850     | • . Knob Set, Parking      |
| 36     | 57619-07G00     | • . Screw, Parking Plate   |
| 37     | 57618-07G00     | • . Washer                 |
| 38     | 57624-07G00     | • . Spring, Return         |
| 39     | 57541-07G00     | Cover, Lever               |



| Ref No | Part No     | Description                |
|--------|-------------|----------------------------|
| 1      | 57211-03G10 | Grip                       |
| 2      | 57100-38F50 | Case Assy, Throttle        |
| 3      | 57121-38F50 | . . Cap                    |
| 4      | 57157-38F50 | . . Gasket                 |
| 5      | 57128-07G00 | . . Screw                  |
| 6      | 57126-07G00 | . . Holder                 |
| 7      | 57127-07G00 | . . Bolt                   |
| 8      | 08310-00053 | . . Nut                    |
| 9      | 02112-05203 | . . Screw                  |
| 10     | 57421-39D20 | Lever, Front Brake         |
| 11     | 57431-04F00 | Bolt, Pivot                |
| 12     | 57433-09F00 | Nut                        |
| 13     | 57460-17C11 | Switch Assy, Stop          |
| 14     | 57465-17C00 | . . Screw                  |
| 15     | 57211-03G10 | Grip                       |
| 16     | 37400-07G10 | Switch Assy, Handle Lh     |
| 17     | 37571-19B01 | . . Lever, Choke           |
| 18     | 37576-19B01 | . . Cover, Choke           |
| 19     | 02112-05457 | . . Screw                  |
| 20     | 02112-05407 | . . Screw                  |
| 21     | 57500-07G01 | Lever Set, Clutch          |
| 22     | 57621-07G00 | . . Lever                  |
| 23     | 57513-07G00 | . . Bolt, Pivot            |
| 24     | 57432-07G00 | . . Washer                 |
| 25     | 08319-21063 | . . Nut                    |
| 26     | 57512-07G00 | . . Holder                 |
| 27     | 01547-06203 | . . Bolt                   |
| 28     | 57442-07G00 | . . Nut, Adjuster          |
| 29     | 57441-45C00 | . . Bolt, Adjuster         |
| 30     | 57800-07850 | . . Lock Set, Parking Lock |
| 31     | 57431-07G00 | . . Bolt, Parking Lock     |
| 32     | 57433-07G00 | . . Washer                 |
| 33     | 57623-07G00 | . . Spacer                 |
| 34     | 08319-21063 | . . Nut                    |
| 35     | 57700-07850 | . . Knob Set, Parking      |
| 36     | 57619-07G00 | . . Screw, Parking Plate   |
| 37     | 57618-07G00 | . . Washer                 |
| 38     | 57624-07G00 | . . Spring, Return         |
| 39     | 57560-07G10 | . . Switch Assy, Clutch    |
| 40     | 57541-07G00 | Cover, Lever               |




| Ref No | Part No         | Description                   |
|--------|-----------------|-------------------------------|
| 1      | 63111-07G00-YU1 | Fender, Rear (yellow)         |
| 1      | 63111-07G00-30H | Fender, Rear (white)          |
| 2      | 63261-07G00     | Shield                        |
| 3a     | 63140-07G10     | Bracket, Rh                   |
| 3b     | 63150-07G10     | Bracket, Lh                   |
| 4      | 01570-06163     | Bolt                          |
| 5      | 09409-07333     | Clip                          |
| 6      | 09169-06045     | Washer, Front                 |
| 7      | 09139-06109     | Bolt                          |
| 8      | 01570-06203     | Bolt, Rear                    |
| 9      | 08319-21063     | Nut                           |
| 10     | 09169-06045     | Washer Rear                   |
| 11     | 63129-07G00     | Cushion                       |
| 12     | 63331-07G00-291 | Mudguard, Footrest Rh (black) |
| 13     | 63341-07G00-291 | Mudguard, Footrest Lh (black) |
| 14     | 09139-06109     | Bolt                          |
| 15     | 09169-06071     | Washer                        |
| 16     | 96200-18A02     | Gauge, Air                    |
| 17     | 09800-21046     | Tool Assy                     |
| 18     | 09822-00004     | Clamp, Wrench                 |
| 19     | 09816-00103     | Hexagon Spanner, 4            |
| 21     | 68111-19B30-GY8 | Emblem, "suzuki"              |
| 21     | 68111-19B30-8YM | Emblem, "suzuki"              |




| Ref No | Part No         | Description           |
|--------|-----------------|-----------------------|
| 1      | 68921-09F00     | Label, Warning        |
| 1      | 68366-20B60     | Label, Warning        |
| 2      | 68366-07G00     | Label, Gear Shifting  |
| 2      | 68366-07G10     | Label, Gear Shifting  |
| 3      | 68931-09F00     | Label, Age 16         |
| 3      | 68367-04640     | Label, Age 16         |
| 4      | 68353-26E02     | Label, Manual Notice  |
| 5      | 68332-07G00     | Label, Tire Air       |
| 5      | 68332-07G10     | Label, Tire Air       |
| 6      | 68382-07G00     | Label, Chain Adjuster |
| 6      | 68382-07G10     | Label, Chain Adjuster |
| 7      | 68928-09F00     | Washer                |
| 8      | 68929-09F00     | Rivet                 |
| 9      | 99011-07G50-03A | Manual, Owner's       |
| 9      | 99011-07G50-28B | Manual, Owner's       |







| Ref No | Part No         | Description           |
|--------|-----------------|-----------------------|
| 1      | 68921-09F00     | Label, Warning        |
| 1      | 68366-20B60     | Label, Warning        |
| 2      | 68366-07G00     | Label, Gear Shifting  |
| 2      | 68366-07G10     | Label, Gear Shifting  |
| 3      | 68931-09F00     | Label, Age 16         |
| 3      | 68367-04640     | Label, Age 16         |
| 4      | 68353-26E02     | Label, Manual Notice  |
| 5      | 68332-07G00     | Label, Tire Air       |
| 5      | 68332-07G10     | Label, Tire Air       |
| 6      | 68382-07G00     | Label, Chain Adjuster |
| 6      | 68382-07G10     | Label, Chain Adjuster |
| 7      | 68623-01B00     | Label, Fuel           |
| 8      | 68928-09F00     | Washer                |
| 9      | 68929-09F00     | Rivet                 |
| 10     | 99011-07G51-03A | Manual, Owner's       |
| 10     | 99011-07G51-28B | Manual, Owner's       |

| Ref No | Part No         | Description               |
|--------|-----------------|---------------------------|
| 1      | 45100-07G01-P21 | Seat Assy                 |
| 2      | 45149-09B00     | • . Cushion               |
| 3      | 45149-07G00     | • . Cushion               |
| 4      | 45141-07G00     | Cushion, Seat Mount Front |
| 5      | 09320-09017     | Cushion, Seat Mount Rear  |






| Ref No | Part No     | Description                 |
|--------|-------------|-----------------------------|
| 1      | 51281-07G00 | Tie Rod, Steering           |
| 2      | 51230-07G10 | Knuckle, Steering Rh        |
| 3      | 51240-07G10 | Knuckle, Steering Lh        |
| 4      | 51210-05G00 | End, Knuckle Steering Upper |
| 5      | 51260-21G00 | Rod, End Rh                 |
| 6      | 51270-21G00 | Rod, End Lh                 |
| 7      | 09140-10043 | Nut, Tie Rod Rh             |
| 8      | 08314-40103 | Nut, Rod End                |
| 9      | 09140-10027 | Nut, Tie Rod Lh             |
| 10     | 04111-20208 | Cotter Pin, Rod End         |
| 11     | 08322-01123 | Washer, Knuckle End         |
| 12     | 08314-40123 | Nut, Knuckle End            |
| 13     | 04111-30208 | Cotter Pin, Knuckle End     |
| 14     | 08331-31306 | Circlip                     |
| 15     | 09162-10008 | Washer, Rod End Lock        |






| Ref No | Part No         | Description                             |
|--------|-----------------|-----------------------------------------|
| 1      | 51650-07G10     | Shaft, Steering                         |
| 2      | 51678-24500     | Dust Seal, Steering Holder (27x38x8.5)  |
| 3      | 51670-24500     | Holder, Steering Shaft                  |
| 4      | 01550-08753     | Bolt                                    |
| 5      | 09280-17003     | O Ring (d:3.1,id:16.8)                  |
| 6      | 51661-19B10     | Bush, Steering Shaft Lower (17x26x36.9) |
| 7      | 51662-19A01     | Dust Seal, Steering Shaft (30x40x14.4)  |
| 8      | 51663-24500     | Dust Seal, Steering Lower (12.2x38x12)  |
| 9      | 09160-12073     | Washer (12.5x32x2.3)                    |
| 10     | 08319-31123     | Nut                                     |
| 11     | 04111-20208     | Cotter Pin                              |
| 12     | 56211-21G00-291 | Clamp, Handlebar Lower (black)          |
| 13     | 56211-27200-291 | Holder, Handlebar                       |
| 14     | 01550-08553     | Bolt                                    |
| 15     | 09164-08015     | Washer                                  |



| Ref No | Part No         | Description                      |
|--------|-----------------|----------------------------------|
| 1      | 52100-07G00-37W | Absorber Assy, Front Shock (red) |
| 2      | 09103-10352     | Bolt, Lower (10x48)              |
| 3      | 09103-10351     | Bolt, Upper (10x38)              |
| 4      | 09159-10058     | Nut                              |
| 5      | 52410-07G00-YD8 | Arm Assy, Suspension Lower Rh    |
| 6      | 52420-07G00-YD8 | Arm Assy, Suspension Lower Lh    |
| 7      | 52430-07G00-YD8 | Arm Assy, Suspension Upper Rh    |
| 8      | 52440-07G00-YD8 | Arm Assy, Suspension Upper Lh    |
| 9      | 09263-17033     | Bearing, Suspension Arm Pivot    |
| 10     | 09263-17034     | Bearing, Upper                   |
| 11     | 52454-43B00     | Seal, Suspension Arm Pivot Dust  |
| 12     | 09285-17001     | Seal, Pivot Inner Dust           |
| 13     | 52455-43B00     | Spacer, Lower                    |
| 14     | 52455-07G00     | Spacer, Upper                    |
| 15     | 09103-10033     | Bolt                             |
| 16     | 09159-10058     | Nut                              |
| 17     | 08211-10281     | Washer                           |


| Ref No | Part No         | Description                   |
|--------|-----------------|-------------------------------|
| 1      | 54110-07G00-YU8 | Hub, Front Wheel (gray)       |
| 2      | 08120-60047     | Bearing, Front Hub Inner      |
| 3      | 09262-15024     | Bearing, Front Hub Outer      |
| 4      | 09284-26002     | Dust Seal Inner               |
| 5      | 09284-21001     | Dust Seal Outer               |
| 6      | 54731-07G00     | Spacer, Front Hub Bearing     |
| 7      | 55310-07G00     | Rim, Front Wheel (10x5.5at)   |
| 8      | 09140-10021     | Nut                           |
| 9      | 08322-01143     | Washer                        |
| 10     | 08314-40143     | Nut, Hub                      |
| 11     | 04111-30308     | Pin, Cotter                   |
| 12     | 09180-15068     | Spacer, Front Axle            |
| 13     | 09180-20119     | Spacer, Fr Axle No.2          |
| 14     | 59211-07G00     | Disc, Front Brake             |
| 15     | 09106-08160     | Bolt, Brake Disc              |
| 16     | 59231-07G10     | Cover, Front Disc             |
| 17     | 09103-06083     | Bolt                          |
| 18     | 55110-07G00     | Tire, Front                   |
| 19     | 43130-24A00     | Valve Assy, Wheel Rim (tr412) |
| 20     | 54138-07G00     | Plate, Front Hub              |






| Ref No | Part No         | Description            |
|--------|-----------------|------------------------|
|        | 59100-38F30-999 | Caliper Assy, Front Rh |
|        | 59300-38F30-999 | Caliper Assy, Front Lh |
| 1      | 59100-38850     | • . Piston Set         |
| 2      | 59100-38860     | •• .. Seal Set, Piston |
| 3      | 59315-13A00     | • . Spring, Pad        |
| 4      | 59386-13A00     | • . Boot               |
| 5      | 59382-13A00     | • . Pin                |
| 6      | 59314-13A00     | • . Washer             |
| 7      | 59105-38F00     | • . Pin, Slide         |
| 8      | 59306-13A00     | • . Spring             |
| 9      | 59384-13A00     | • . Plug, Dust         |
| 10     | 59303-13A00     | • . Boot               |
| 11     | 59345-00B20     | • . Pin                |
| 12     | 59151-38F00     | • . Bracket, Rh        |
| 12     | 59351-38F00     | • . Bracket, Lh        |
| 13     | 59121-01A00     | • . Bleeder            |
| 14     | 59122-01A00     | • . Cap                |
| 15     | 59300-42860     | Pad & Shim Set, R      |
| 15     | 59300-42870     | Pad & Shim Set, L      |
| 16     | 59371-13A00     | • . Shim, Rh           |
| 16     | 69372-00B20     | • . Shim, Lh           |
| 17     | 07120-08163     | Bolt (8x16)            |

| Ref No | Part No     | Description            |
|--------|-------------|------------------------|
| 1      | 09360-10042 | Bolt                   |
| 2      | 09161-10009 | Washer (10x15x1.5)     |
| 3      | 59480-07G00 | Hose, Front Brake No.1 |
| 4      | 59240-07G00 | Hose, Front Brake No.2 |
| 5      | 59261-07G00 | Clamp, Hose No.2 Rh    |
| 6      | 59271-07G00 | Clamp, Hose No.2 Lh    |
| 7      | 01550-06103 | Bolt                   |
| 8      | 59250-07G00 | Pipe, Front Brake      |
| 9      | 01547-06123 | Bolt                   |
| 10     | 09403-07325 | Clamp, Fr Brake Pipe   |
| 11     | 59281-07G00 | Cover, Fr Brake Pipe   |









| Ref No | Part No     | Description                 |
|--------|-------------|-----------------------------|
| 1      | 59600-31D00 | Cylinder Assy, Front Master |
| 2      | 59600-04810 | • . Piston/cup Set          |
| 3      | 59667-44B00 | • . Diaphragm               |
| 4      | 69669-24A01 | • . Cap                     |
| 5      | 69689-49300 | • . Screw, Cap              |
| 6      | 59671-36500 | • . Holder                  |
| 7      | 59675-19C00 | • . Bolt                    |
| 8      | 59748-15400 | • . Separator               |
|        | 59749-15400 | • . Plate                   |







| Ref No | Part No     | Description                     |
|--------|-------------|---------------------------------|
| 1      | 61100-07890 | Swinging Arm Set, Rear          |
| 2      | 09263-22017 | • . Bearing, Pivot              |
| 3      | 61261-07G00 | • . Bush, Rr Swinging Arm Pivot |
| 4      | 09285-22001 | Seal, Pivot Bearing             |
| 5      | 61252-07G00 | Spacer                          |
| 6      | 61262-28C10 | Cover, Pivot Dust               |
| 7      | 08211-17341 | Washer, Thrust                  |
| 8      | 61211-07G00 | Shaft, Pivot                    |
| 9      | 08319-31168 | Nut                             |
| 10     | 61273-07G00 | Buffer, Chain Touch Defense     |
| 11     | 09116-06152 | Bolt                            |
| 12     | 61421-01C01 | Plate, Chain Adjuster           |
| 13     | 64718-07G00 | Washer, Axle Housing Set Fr     |
| 14     | 64719-07G00 | Washer, Axle Housing Set Rr     |
| 15     | 09108-08209 | Bolt, Chain Adjuster            |
| 16     | 08319-31087 | Nut, Chain Adjuster             |
| 17     | 61470-07G00 | Washer, Axle Housing Set Fr     |
| 18     | 61480-07G00 | Washer, Axle Housing Set Rr     |
| 19     | 61425-43B00 | Boot, Chain Adjuster Bolt       |
| 20     | 61390-07G10 | Guard, Swinging Arm Under       |
| 21     | 61393-09F00 | Bolt, Guard                     |
| 22     | 09106-08154 | Bolt, Guard Center              |
| 23     | 61396-07G00 | Buffer, Swgarm Guard No.1       |
| 24     | 61222-05A01 | Cap, Rr Swinging Arm            |




| Ref No | Part No     | Description                       |
|--------|-------------|-----------------------------------|
| 1      | 61100-07890 | Swinging Arm Set, Rear            |
| 2      | 09263-22017 | • . Bearing, Pivot                |
| 3      | 61261-07G00 | • . Bush, Rear Swinging Arm Pivot |
| 4      | 09285-22001 | Seal, Pivot Bearing               |
| 5      | 61252-07G00 | Spacer                            |
| 6      | 61262-28C10 | Cover, Pivot Dust                 |
| 7      | 08211-17341 | Washer, Thrust                    |
| 8      | 61211-07G00 | Shaft, Pivot                      |
| 9      | 08319-31168 | Nut                               |
| 10     | 61273-07G00 | Buffer, Chain Touch Defense       |
| 11     | 09116-06192 | Bolt                              |
| 12     | 61421-01C01 | Plate, Chain Adjuster             |
| 13     | 64718-07G00 | Washer, Axle Housing Set Front    |
| 14     | 64719-07G00 | Washer, Axle Housing Set Rear     |
| 15     | 09108-08209 | Bolt, Chain Adjuster              |
| 16     | 08319-31087 | Nut, Chain Adjuster               |
| 17     | 61470-07G00 | Washer, Axle Housing Set Front    |
| 18     | 61480-07G00 | Washer, Axle Housing Set Rear     |
| 19     | 61425-43B00 | Boot, Chain Adjuster Bolt         |
| 20     | 61305-07G01 | Guard Set, Swinging Arm Under     |
| 21     | 61390-07G11 | • . Guard, Swinging Arm Under     |
| 22     | 61396-07G10 | • . Buffer, Swgarm Guard          |
| 23     | 09160-04027 | • . Washer, Buffer                |
| 24     | 09229-04048 | • . Rivet, Buffer                 |
| 25     | 61393-09F00 | Bolt, Guard                       |
| 26     | 09106-08154 | Bolt, Guard Center                |
| 27     | 61222-05A01 | Cap, Rear Swinging Arm            |




| Ref No | Part No     | Description                     |
|--------|-------------|---------------------------------|
| 1      | 61101-07820 | Swinging Arm Set, Rear          |
| 2      | 09263-22017 | • . Bearing, Pivot              |
| 3      | 61261-07G00 | • . Bush, Rr Swinging Arm Pivot |
| 4      | 09285-22001 | Seal, Pivot Bearing             |
| 5      | 61252-07G00 | Spacer                          |
| 6      | 61262-28C10 | Cover, Pivot Dust               |
| 7      | 08211-17341 | Washer, Thrust                  |
| 8      | 61211-07G10 | Shaft, Pivot                    |
| 9      | 08319-31168 | Nut                             |
| 10     | 61273-07G00 | Buffer, Chain Touch Defense     |
| 11     | 09116-06192 | Bolt                            |
| 12     | 61421-07G00 | Plate, Chain Adjuster           |
| 13     | 09108-12014 | Bolt, Chain Adjuster            |
| 14     | 09160-20081 | Washer, Chain Adjuster Nut      |
| 15     | 08331-31206 | Circlip                         |
| 16     | 61422-07G00 | Nut, Chain Adjuster             |
| 17     | 09103-12074 | Bolt, Fr                        |
| 18     | 09103-12075 | Bolt, Rr                        |
| 19     | 09160-12103 | Washer                          |
| 20     | 61470-07G10 | Washer, Axle Housing Set Fr     |
| 21     | 61480-07G10 | Washer, Axle Housing Set Rr     |
| 22     | 61305-07G10 | Guard Set, Swinging Arm Under   |
| 23     | 61391-07G10 | • . Guard, Swinging Arm Under   |
| 24     | 61396-07G20 | • . Buffer, Swgarm Guard        |
| 25     | 09160-04027 | • . Washer, Buffer              |
| 26     | 09229-04048 | • . Rivet, Buffer               |
| 27     | 61393-09F10 | Bolt, Guard                     |
| 28     | 09106-08076 | Bolt, Guard Center              |
| 29     | 08322-01103 | Washer, Guard Center            |
| 30     | 61222-05A01 | Cap, Rr Swinging Arm            |
| 31     | 61425-07G00 | Boot, Chain Adjuster Bolt       |



| Ref No | Part No         | Description                     |
|--------|-----------------|---------------------------------|
| 1      | 62600-07810     | Lever Set, Cushion              |
| 2      | 09263-20086     | • . Bearing, Front (20x27x15)   |
| 3      | 09263-20086     | • . Bearing, Center (20x27x15)  |
| 4      | 09263-20083     | • . Bearing, Rear (20x26x12)    |
| 5      | 62317-37F00     | Spacer, Front                   |
| 6      | 62624-14500     | Seal, Front Dust                |
| 7      | 62658-07G00     | Bolt, Front                     |
| 8      | 09159-12056     | Nut                             |
| 9      | 62646-37F00     | Spacer, Center                  |
| 10     | 62624-14500     | Seal, Center Dust               |
| 11     | 62621-37F00     | Bolt, Center                    |
| 12     | 09159-12056     | Nut                             |
| 13     | 62684-36E00     | Spacer, Rear                    |
| 14     | 09284-20001     | Seal, Rear                      |
| 15     | 62647-37F00     | Spacer, Cushion Lever Side      |
| 16     | 08351-31008     | Nipple, Grease                  |
| 17     | 62600-07820     | Rod Set, Rear Cushion           |
| 18     | 09263-20086     | • . Bearing, Rod (20x27x15)     |
| 19     | 62624-14500     | Seal, Dust                      |
| 20     | 62646-07G00     | Spacer, Rod                     |
| 21     | 62647-37F00     | Spacer, Rod Side                |
| 22     | 62621-07G00     | Bolt, Rod                       |
| 23     | 09159-12056     | Nut                             |
| 24     | 08351-31008     | Nipple, Grease                  |
| 25     | 62100-07G01-37W | Absorber Assy, Rear Shock (red) |
| 25     | 62100-07G11-37W | Absorber Assy, Rear Shock (red) |
| 26     | 62311-14501     | Bolt, Upper                     |
| 27     | 09103-10325     | Bolt, Lower                     |
| 28     | 09159-10058     | Nut, Upper                      |
| 29     | 09159-10067     | Nut, Lower                      |
| 30     | 62681-07G00     | Guard, Rear Cushion Lever       |
| 31     | 09139-06120     | Screw                           |




| Ref No | Part No         | Description                   |
|--------|-----------------|-------------------------------|
| 1      | 64110-07G00-YU8 | Hub, Rear Wheel (gray)        |
| 2      | 65310-07G00     | Rim, Rear Wheel (9x8.0at)     |
| 3      | 09140-10021     | Nut                           |
| 4      | 09164-20002     | Washer                        |
| 5      | 09141-20002     | Nut, Hub                      |
| 6      | 04111-40408     | Cotter Pin                    |
| 7      | 64710-07G00     | Axle, Rear                    |
| 8      | 64871-07G00     | Nut, Rear Axle Rh             |
| 9      | 64715-07G00     | Housing, Rr Axle Bearing      |
| 10     | 64731-07G00     | Spacer, Rr Axle Bearing       |
| 11     | 08123-60087     | Bearing, Rear Axle            |
| 12     | 09283-50006     | Seal, Rr Axle Bearing Dust    |
| 13     | 09103-10076     | Bolt, Housing Front Rh        |
| 14     | 09103-10350     | Bolt, Housing Rear Rh         |
| 15     | 09103-12026     | Bolt, Housing Front Lh        |
| 16     | 09103-12027     | Bolt, Housing Rear Lh         |
| 17     | 09160-12102     | Washer, Axle Housing Set Lh   |
| 18     | 69211-07G00     | Disc, Rear Brake              |
| 19     | 09106-08160     | Bolt, Disc                    |
| 20     | 65110-07G00     | Tire, Rear                    |
| 21     | 43130-24A00     | Valve Assy, Wheel Rim (tr412) |




| Ref No | Part No         | Description                   |
|--------|-----------------|-------------------------------|
| 1      | 64110-07G00-YU8 | Hub, Rear Wheel (gray)        |
| 2      | 65310-07G00     | Rim, Rear Wheel (9x8.0at)     |
| 3      | 09140-10021     | Nut                           |
| 4      | 09164-20002     | Washer                        |
| 5      | 09141-20002     | Nut, Hub                      |
| 6      | 04111-40408     | Cotter Pin                    |
| 7      | 64710-07G10     | Axle, Rear                    |
| 8      | 64871-07G00     | Nut, Rear Axle Rh             |
| 9      | 64715-07G10     | Housing, Rr Axle Bearing      |
| 10     | 64731-07G00     | Spacer, Rr Axle Bearing       |
| 11     | 08123-60087     | Bearing, Rear Axle            |
| 12     | 09283-50006     | Seal, Rr Axle Bearing Dust    |
| 13     | 69211-07G00     | Disc, Rear Brake              |
| 14     | 09106-08160     | Bolt, Disc                    |
| 15     | 65110-07G00     | Tire, Rear                    |
| 16     | 43130-24A00     | Valve Assy, Wheel Rim (tr412) |


| Ref No | Part No         | Description                    |
|--------|-----------------|--------------------------------|
| 1      | 64110-07G00-YU8 | Hub, Rear Wheel (gray)         |
| 2      | 65310-07G00     | Rim, Rear Wheel (9x8.0at)      |
| 3      | 09140-10021     | Nut                            |
| 4      | 09164-20002     | Washer                         |
| 5      | 09141-20002     | Nut, Hub                       |
| 6      | 04111-40408     | Cotter Pin                     |
| 7      | 64870-19A00     | Nut, Rear Axle                 |
| 8      | 09164-38001     | Washer, Rear Axle              |
| 9      | 64611-07G00     | Flange, Rear Sprocket Mounting |
| 10     | 64511-07G00     | Sprocket, Rear (nt:40)         |
| 11     | 09103-10354     | Bolt                           |
| 12     | 09164-10011     | Washer                         |
| 13     | 65110-07G00     | Tire, Rear                     |
| 14     | 43130-24A00     | Valve Assy, Wheel Rim (tr412)  |











| Ref No | Part No         | Description        |
|--------|-----------------|--------------------|
|        | 69100-07G00-999 | Caliper Assy, Rear |
| 1      | 69100-19850     | • Piston Set       |
| 2      | 69100-13820     | • Seal Set, Piston |
| 3      | 59315-13A00     | • Spring, Pad      |
| 4      | 59386-13A00     | • Boot             |
| 5      | 59382-13A00     | • Bolt             |
| 6      | 59314-13A00     | • Washer           |
| 7      | 69305-19A00     | • Pin              |
| 8      | 59303-13A00     | • Boot             |
| 9      | 59306-13A00     | • Spring           |
| 10     | 69151-07G00     | • Bracket          |
| 11     | 59345-13A00     | • Pin              |
| 12     | 59346-13A00     | • Washer           |
| 13     | 59121-01A00     | • Bleeder          |
| 14     | 59122-01A00     | • Cap, Bleeder     |
| 15     | 69320-07G00     | • Parking          |
| 16     | 69326-19A01     | • Packing          |
| 17     | 69321-19A00     | • Bolt             |
| 18     | 69322-19A00     | • O Ring           |
| 19     | 69329-19A00     | • Boot             |
| 20     | 69325-19A00     | • Arm              |
| 21     | 69327-19A00     | • Bolt, Adjust     |
| 22     | 69323-19A00     | • Nut              |
| 23     | 69328-19A00     | • Spring           |
| 24     | 69100-07810     | Pad Set            |
| 25     | 09103-08156     | Bolt               |



| Ref No | Part No         | Description        |
|--------|-----------------|--------------------|
| 1      | 69100-07G10-999 | Caliper Assy, Rear |
| 2      | 69100-19850     | • Piston Set       |
| 3      | 69100-13820     | • Seal Set, Piston |
| 4      | 59315-13A00     | • Spring, Pad      |
| 5      | 59386-13A00     | • Boot             |
| 6      | 59382-13A00     | • Bolt             |
| 7      | 59314-13A00     | • Washer           |
| 8      | 69305-19A00     | • Pin              |
| 9      | 59303-13A00     | • Boot             |
| 10     | 59306-13A00     | • Spring           |
| 11     | 69151-07G00     | • Bracket          |
| 12     | 59345-13A00     | • Pin              |
| 13     | 59346-13A00     | • Washer           |
| 14     | 59121-01A00     | • Bleeder          |
| 15     | 59122-01A00     | • Cap, Bleeder     |
| 16     | 69320-07G00     | • Parking          |
| 17     | 69326-19A01     | • Packing          |
| 18     | 69321-19A00     | • Bolt             |
| 19     | 69322-19A00     | • O Ring           |
| 20     | 69329-19A00     | • Boot             |
| 21     | 69325-19A00     | • Arm              |
| 22     | 69127-07G00     | • Bolt, Adjust     |
| 23     | 69323-19A00     | • Nut              |
| 24     | 69328-19A00     | • Spring           |
| 25     | 69100-07810     | Pad Set            |
| 26     | 09103-08156     | Bolt               |



| Ref No | Part No     | Description                |
|--------|-------------|----------------------------|
| 1      | 69600-07G00 | Cylinder Assy, Rear Master |
| 2      | 69600-34820 | • . Piston/cup Set         |
| 3      | 69691-00A00 | • . Boot                   |
| 4      | 69670-07G00 | • . Rod, Push              |
| 5      | 69692-07G00 | • . Yoke                   |
| 6      | 69693-05A00 | • . Nut                    |
| 7      | 69672-00B20 | • . Connector              |
| 8      | 69674-00B20 | • . Circlip                |
| 9      | 69686-34200 | • . O Ring                 |
| 10     | 09103-06202 | Bolt                       |
| 11     | 69740-03D00 | Tank Assy, Rear Reservoir  |
| 12     | 69667-00B20 | • . Diaphragm              |
| 13     | 69668-00B20 | • . Plate                  |
| 14     | 69669-03D00 | • . Cap                    |
| 15     | 01547-06123 | Bolt                       |
| 16     | 69730-07G00 | Hose, Rear Reservoir Tank  |
| 17     | 09401-12404 | Clip                       |
| 18     | 69480-07G00 | Hose, Rear Brake           |
| 19     | 09360-10042 | Bolt, Union, 10x1.25x22    |
| 20     | 09161-10009 | Washer, 10x15x1.5          |
| 21     | 09200-08048 | Pin                        |
| 22     | 09160-08119 | Washer                     |
| 23     | 04111-20158 | Pin, Cotter                |
| 24     | 69260-07G00 | Clamp, Rr Brake Hose       |
| 25     | 01547-06103 | Bolt                       |
| 26     | 69738-07G00 | Guide, Rr Rsvr Tank Hose   |



| Ref No | Part No     | Description                |
|--------|-------------|----------------------------|
| 1      | 99104-32030 | Thread Lock, Super (1363a) |
| 1      | 99000-32050 | Thread Lock, Super (1342)  |
| 1      | 99000-32100 | Thread Lock, Super (1305)  |
| 1      | 99104-32020 | Thread Lock, Super (1361a) |
| 1      | 99000-32130 | Thread Lock, Super (1360)  |
| 2      | 99000-32040 | Thread Lock Cement         |
| 3      | 99000-31140 | Suzuki Bond (1207b)(black) |
| 3      | 99000-31110 | Suzuki Bond (1215)         |
| 4      | 99000-25030 | Suzuki Super Grease        |
| 5      | 99000-25140 | Suzuki Moly Paste          |
| 6      | 99000-25110 | Suzuki Pbc Grease          |